

Many modern amplifiers do not have a phono input for turntables or other low level audio sources. This preamplifier/switch box fixes that problem and also provides two selectable inputs to a stereo line level output which feeds into the auxiliary input on your stereo amplifier. Requires 12V DC - either use a 12V battery or a 240V mains adaptor. Plastic case construction with gold RCA connectors & rubber suction feet.

Requires 12VDC. For suitable mains power supply use MP3011.

Specifications:

- Input sensitivity: 2.5mV
- Input impedance: 47kohm @ 1kHz
- Output: 180mV
- Current draw 20mA
- Output impedance: 47kohm
- Size 130(L) x 90(D) x 34(H)mm

A/V Switcher or Converter

Input Connection	RCA
Number of Outputs	1pc
Switcher/Converter Type	Manual Switcher
Output Type	Audio
Output Connection	RCA
Input type	Audio
Number of inputs	2pc

Product Dimensions

Length	160mm
Diameter	100mm
Height	40mm

Warranty: 12 Months